


Ersatzteilliste

Artikelnummer:

216071

Sprachen:

de, en



BERNER

216071

Spare parts

Nr.	Code	Berner Art.	Description
1	AM86.025		Spring side case cover
2	AM86.045		Spacer
3	7000.060		Shaft support
4	003.030		Washer
5	806.046 (2)		Cable guide roller
6	AM86.020		Half-case spring side
7	500.092 (2)		Pin bracket
8	815.086		Bracket
9	806.057		Spring shaft
10	003.027		Washer
11	AM86.034		Half-reel spring side
12	806.058	244154	Spring
13	AM86.032		Half-reel collector side
14	AM86.052		Reel shaft
15	AM86.060		Reel shaft holder
16	AM86.054 (3)		Washer
17	7000.046		Ratchet
18	AM86.010		Half-case collector side
19	7000.048		Ratchet spring
20	000.535 (2)	244054	OR Gasket
21	AM86.062	244051	Hub
22	000.251	244053	OR Gasket
23	AM86.340	244052	Ø12 - 1,5 m enter hose
24	000.780		Seeger ring
25	AM86.065	244049	Staple
26	AM70.028		Cover
27	AM86.040		Case spring side stopper
	AM86.363	244047	Ø12 - 16 m PVC hose