


Ersatzteilliste

Artikelnummer:

216040

Sprachen:

de, en



BERNER

216040

Spare parts

Nr.	Code	Berner Art.	Description
1	E500.020		Half-case spring side
2	500.092 (2)	244089	Pin bracket
3	AM70.070	244077	Bracket
4	003.030		Washer
5	7000.042	244086	Spring shaft
6	003.027	244088	Washer
7	AM70.056	244079	Spring case cover
8	E500.090	244158	Spring
9	AM85.054	244075	Half-Reel Spring Side
10	AM85.052	244076	Half-Reel Collector Side
11	AM85.060		Reel shaft
12	AM85.068		Bushing
13	7000.046	244084	Ratchet
14	E500.010		Half-case collector side
15	7000.048	244083	Ratchet spring
16	000.316 (2)	244100	Washer
17	000.270 (2)	244101	OR Gasket
18	805.060	244069	Hub
19	000.728	244099	Seeger ring
20	E500.080		Spacer
21	AM40.026		Cover
	E500.062	244068	15 m - Ø10 Hose