


Ersatzteilliste

Artikelnummer:

216072

Sprachen:

de, en



BERNER

216072

Spare parts

Nr.	Code	Berner Art.	Description
1	AM40.021		Half-case spring side
2	4000.042 (2)		Cable guide roller
3	AM40.062	244093	Bracket
4	810.082 (2)	244096	Pin bracket
5	4000.062	244156	Spring
6	AM40.050		Reel
7	PRO310.030	244063	Collector
8	PRO210.105		Cable clamp
9	PRO310.060 (2)		Washer
10	PRO210.339		Insulator ring
11	AM40.038	244094	Cover
12	600.008	244062	Grommet
13	831.500		Cable clamp
14	831.764	244095	Ratchet spring
15	831.762	244097	Ratchet
16	4000.332	244061	Brush
17	PRO210.062 (2)		Brush spacer
18	4000.312	244060	Brush
19	PRO210.326 (2)		Brush support
20	4000.342 (2)	244059	Brush
21	AM40.011		Half-case collector side
22	9000.152		Thermo-switch
23	5000.004		Trip free group
	4315.046	244190	15 m - 3G1,5 cable with schuko plug